,ılı, Bardac'ıı' drives'||'

# T3-OPPAD

TFT Remote Keypad **IP55** 



# **General Specification**

Compatible Drives:	E3, P2, V3
Signal Interface:	CV Standard 8-way RJ45 connector
Supply Input:	24V + / - 10%, DC, 30mA
RS485 Signal:	Industry standard 2-wire +5V differential
Environmental:	Operational: -10 50°C
	Storage: -40°C 60°C
Relative Humidity:	< 95% (non condensing)
Protection Rating:	IP55
Max Cable Length:	25m / 82.5ft shielded twisted pair

### Mechanical Installation Dimensions

### **Through Panel Mount**

The panel on to which the T3-OPPAD is to be mounted should be cut out in accordance with the diagram below.



Cable Requirements



**CAUTION!** Incorrect cable connection may damage the drive. Extra care should be taken when using third party cable.

### **Allowed System Configurations**



Different drive models can be used on the same T3-OPPAD network provided a unique communications address is assigned to each. **NOTE** Cannot be used with Master – Slave or Cascade Control

### **Keypad and Display Layout**

The illustration below explains the main features of the T3-OPPAD. Please note that some features and display messages are specific to certain variants of the drive family.



### **Easy Startup**

#### To setup the drive communication address

By default, the T3-OPPAD will try to communicate with the drive that has Address 1 in the network after powering up for the first time. The T3-OPPAD will display **"Scanning for Drive 01."** after power up, which indicates that the T3-OPPAD is searching for the drive with the correct drive address in the network. Once the drive has been found, the message **"Load..."** will be displayed on the T3-OPPAD, which indicates that the T3-OPPAD is reading the configuration information from the drive. Usually it will take 1~2 seconds for the T3-OPPAD to read this information. After the data has been loaded, the T3-OPPAD will display the drive real time status.

**NOTE** In the case where the keypad is connected to a drive where the network address is not 1, the following steps can be used to set the address of the drive



#### Working with Multiple Drive Networks

When the T3-OPPAD is used on networks with multiple drives, the user can change the drive address to set up communication with another drive in the same drive network at anytime.

Select Drive Address xx	Select Drive Address xx	Select Drive Address xx
Briefly press the Stop and Down keys to display the above message.	Use the Up and Down arrows to select the desired address.	After selecting the new address, press the Stop and Down keys to establish communications with the drive.

NOTE For detailed parameter listing and functional setup, please refer to the corresponding drive user guide

#### Networks with 2 T3-OPPADs connected

A maximum of 2 T3-OPPADs can be connected within the same drive network to communicate with the same drive or different drives. When using two T3-OPPADs simultaneously on a network, the user must change the T3-OPPAD Device Number on the second T3-OPPAD to ensure correct operation. All T3-OPPAD units are set to Device Number 1 by default.

Select OPPAD ID xx	Select OPPAD ID xx	Select OPPAD ID xx
		$\bigcirc \bigcirc \bigcirc \frown$
		<i>d</i> )
To change the Device	Use the Up and Down	Press the Stop key
Number, press the	arrows to select the	to return ro normal
Navigate, Stop and	desired T3-OPPAD	operation.
Down keys together.	Numer (1 or 2).	

## Changing the Display Language

STOP	Select Language Español Deutsch English	Select Language Español Deutsch English	
Hold down the Start and Up keys for >1 s	Use the Up and Down arrows to select a language.	Press the Navigate button to select.	

# **Operating Displays**

Inhibit / STO Active	Drive Stopped	Drive Running Output Frequency Display	Drive Running Output Current Display	Drive Running Motor Power Display	Drive Running Motor Speed Display
Name 01	Name 01	Output Frequency 01	Motor Current 01	Motor Power 01	Motor Speed 01
INHIBIT	STOP	23.7Hz	15.3A	6.9kW	<b>718rpm</b>
15kW 400V 3Ph	15kW 400V 3Ph	15.3A 6.9kW	6.9kW 23.7Hz	23.7Hz 15.3A	23.7Hz 15.3A
© ©⊽	COJ ♦od ®⊽				
Drive Inhibited. The STO connections are not made.	Drive Stopped / Disabled.	Drive is enabled / running, display shows the output frequency (Hz). Press the Navigate key to select alternative displays.	Press the Navigate key for < 1 second. The display will show the motor current (Amps).	Press the Navigate key for < 1 second. The display will show the motor power (kW).	If P1-10 > 0, pressing the Navigate key for < 1 second will display the motor speed (Rpm).

# Additional Display Messages

Auto Tuning in Progress	External 24VDC Supply	Overload	Fire Mode
	Name 01	Name 01	Fire Mode
Auto-tuning	Ext 24V	ol 23.7Hz	
	External 24V mode	15.3A 6.9kW	
		$\textcircled{\begin{tabular}{c} \begin{tabular}{c} ta$	
Auto tune in progress.	The drive control board is powered only from an external 24 Volt source, with no mains power applied.	Indicates an Overload condition. Output current exceeds the motor rated current.	Display shows 'Fire Mode'.

Switchir Re	ng Frequency duction	Mains Loss		Maintenance Time Elapsed			
Name	01	Name	01	Name	01	Name	01
SF↓	23.7Hz	ML	23.7Hz	OL	23.7Hz	ĭ	23.7Hz
15.3A		15.3A	6.9kW	15.3A	6.9kW	15.3A	6.9kW
							$\Box$
$\bigcirc$	$\bigcirc \bigtriangleup$		$\bigcirc \bigtriangleup$		$\bigcirc \bigtriangleup$		$\Box$
C	$\square$		$\Box$	C	$\square \Box$		$\Box$
Switching f	frequency is	The incomi	ng mains	The motor	is in overload	The user prog	ırammable
reduced, c	lue to high	power sup	ply has been	drawing a	current higher	maintenance	reminder time
heatsink te	mperature.	disconnect	ed or is missing.	than its rate	ed current.	has elapsed.	

# **Changing Parameters**

	Name 01	Name 01	Name 01	Name 01	Name 01
Stop	P1-01	P1-08	30.0A ‡	P1-08	Stop
15kW 400V 3Ph	50.0Hz	30.0A	<b>P1-08</b> ↑30.0 ↓3.0	30.0A	15kW 400V 3Ph
Press and hold the Navigate key > 2 seconds.	Use the Up and Down keys to select the required parameter. Display will show the present parameter value on the lower line of the display.	Press the Navigate key for < 1 second.	Adjust the value using the Up and Down keys. Display will show the maximum and minimum possible settings on the lower line of the display.	Press for < 1 second to return to the parameter menu.	Press for > 2 seconds to return to the operating display.

## Parameter Factory Reset / User Reset

Factory Parameter	Reset :		User Parameter Re	eset :	
Name 01	Name 01	Name 01	Name 01	Name 01	Name 01
Stop	P-Def	Stop	Stop	U-Def	Stop
15kW 400V 3Ph	50.0Hz	15kW 400V 3Ph	<b>P1-08</b> ↑30.0 ↓3.0	30.0A	15kW 400V 3Ph
Cubb Caller					
Press and hold the	The display shows	The display	Press and hold the	The display shows	The display
Up, Down, Start	P-def. Briefly press	returns to Stop. All	Up, Down and Stop	U-def. Briefly press	returns to Stop.
and Stop keys for	the Stop key.	parameters are	keys for >2s.	the Stop key.	All parameters
>2s.		reset to Factory			are reset to User
		defaults.			Defaults.

### **Drive Fault Messages and Trip Codes**

See drive User Guide for further information.

#### **Further Status Messages and Troubleshooting**

T3-OPPAD uses various display messages to indicate different working status. See the following table for more information.

#### **Status Messages**

Message	Explanation
Scanning for Drive	The T3-OPPAD is searching for the drive with address 'xx' in the network.
xx	
Load	The T3-OPPAD has found the drive in the network and is loading the initialisation information from the drive.
SC-OBS	The communication link between the drive and T3-OPPAD has failed.
Select Language	Displayed in the language selection screen, with a list of available languages. Press the Navigate key to select a language
Select drive address xx	Displayed when selecting the address of the drive that the T3-OPPAD should try to communicate with. Press the Stop key to select the drive address.
Select T3-OPPAD ID	Displayed when selecting the T3-OPPAD ID (1 or 2) so that two T3-OPPADs can be connected to a single drive, or network of multiple drives.

#### Troubleshooting

Symptom	Explanation
Select drive address	The T3-OPPAD failed to successfully communicate with the specified drive address in the network.
xx displayed after	Check that the RJ45 data cable connection is correct. Check that the drive with address XX is available in the network.
'SCAN' message	If XX > 1 and only one T3-OPPAD is connected, then check the T3-OPPAD device number, make sure the number is 1.
Display 'Err-id' on power up	This normally occurs when there are two T3-OPPAD units in the same drive network and both of them have the same device number. Check and change the device number of one T3-OPPAD.
Display 'Err-id' during normal operation	This normally occurs when the user plugs a second T3-OPPAD into the drive network. Change the device number of one of the T3-OPPAD units.
Display	Communication link between the T3-OPPAD and drive has failed during operation.
'SC-OBS'	Check the electrical connection, and make sure the cable is connected correctly between the T3- OPPAD and the drive. Press 'STOP' button to enable the T3-OPPAD to search for the drive again.



82-OPTFT-IN\_V2.00

#### **Bardac Drives**

40 Log Canoe Circle. Stevensville, MD 21666 (410) 604-3400 | (888) 667-7333

bardac.com | driveweb.com | automationthings.com