
INTRODUCTION TO DRIVELINK AND LOGGER CONFIGURATION UTILITIES

Bardac '|||'
drives '|||'

CONTENT

DriveLink	5
Communications Setup	6
Loading a Vysta program	8
Loading System Code (E-Series and RVSx Series)	9
Modbus Logger	11
Setup	11
Operation	12
Reading and Writing System Variable Data	13
Reading and Writing Vysta Variable Data	13
Logging Data to a File	14

REVISION HISTORY

REVISION HISTORY		
C	19/02/2002	Drivelink updated to Ver 2.7.1 & Vista upgraded to Vysta
B	6/10/2000	Drivelink updated to Ver 2.4.0 & Monitor replaced by Logger
A	26/03/2000	Created

